



Pos.	Artikelbeschreibung	Description of item	Artikel Nr./Item No.
1	Thermostat, Betriebsthermostat	Thermostat, main thermostat	02020341
2	Schalter, Backofenfunktionen	Switch, oven functions	06030034
3	Lüfter komplett	Complete fan	02020340
4	Glühlampe 15 W, E 14, 300 °C	Bulb 15 W, E 14, 300 °C	014034
5	Rückwand	Back panel	02020339
6	Glühlampe komplett	Bulb complete	042477
7	Abdeckung unten	Bottom cover	02020342
8	Isolierung hinten	Back insulation	02020343
9	Isolierung	Insulation	02020331
10	Ofenkammer	Oven chamber	02020314
11	Dichtung z. Backofentür	Gasket f. oven door	02020312
12	Backofenrost 443x350x10	Oven grid 443x350x10	132647
13	Backblech 444x362x34	Baking tray 444x362x34	132646
14	Backblech MF6430	Baking tray MF6430	206203
15	Dichtung z. Glasscheibe	Gasket f. glass plate	02020320
16	Türrahmen innen	Inner door frame	02020319
17	Türgriff z. Backofen	Door handle f. oven	02020317
18	Türrahmen außen	Outer door frame	02020318
19	Glasscheibe m. eingefärbtem Rahmen	Glass plate w. coloured frame	02020323
20	Türscharnier z. Backofen bis Seriennr. 013516/12/17	Door hinge f. oven until serial no 013516/12/17	02020316
	Scharnier ab Seriennr. 013516/12/17	Hinge from serial no 013516/12/17	E02026919
21	Gegenstück z. Türscharnier bis Seriennr. 013516/12/17	Counterpiece f. door hinge until serial no 013516/12/17	02020315
	Gegenstück z. Scharnier, Set ab Seriennr. 013516/12/17	Counterpiece of hinge, set from serial no 013516/12/17	E02026920
22	Glasscheibe innen	Internal glass	02020321
23	Halteblech	Holding plate	02020322
24	Heizkörper, Unterhitze	Heating element, bottom heat	02020330
25	Heizkörper, Oberhitze	Heating element, top heat	02020329
26	Knebel, Backofenfunktionen	Knob, oven functions	02019958
27	Knebel 50° - max	Knob 50° - max	02019959
28	Kontrolllampe weiß	White indicator light	06061072
	Kontrolllampe grün	Green indicator light	06061073
29	Feder z. Knebel	Spring f. knob	05900242
30	Knebel m. Feder	Knob w. spring	02008677
31	7-Takt Schalter mit Anschlussfahnen	7 cycles switch with flat pin	06030014
32	Kochplatte, 2000 W, 230 V	Cooking plate, 2000 W, 230 V	E01818463194
33	Frontblende	Front panel	E02019963
o.Abb/n.pic	Tür z. Backofen bis Seriennr. 013516/12/17	Oven door until serial no 013516/12/17	E02024393
	Tür, komplett ab Seriennr. 013516/12/17	Door, complete from serial no 013516/12/17	E01217821
	Sicherheitsthermostat	Safety thermostat	E06011145